



## CONCRETE POUR INSTALLATION INSTRUCTIONS

1. PREWIRE FIXTURE USING APPROPRIATE CONDUIT & FITTINGS.
2. POSITION BOTTOM EDGE OF LUMINAIRE ON WOODEN POUR FORM.
3. NAIL IN PLACE THROUGH ROUND HOLES IN MOUNTING BRACKET.
4. POUR CONCRETE, LET HARDEN, REMOVE FORMS.
5. NIP OFF NAIL FLUSH WITH CEILING.
6. FINISH AS NECESSARY.